

REMOVE EXISTING TEE. INSTALL WATER MAIN IN PLACE OF TEE WITH COUPLINGS TO EXISTING WATER MAIN.

ABANDON LATERAL IN PLACE (PLUG ENDS)

REMOVE EXISTING VALVE, BOX, FIRE HYDRANT AND BURY. PLUG ALL OPENINGS.

NOTES:

1. TRAFFIC PLAN REQUIRED. SUBMIT FOR APPROVAL TO ENGINEERING DEPARTMENT PRIOR TO WORK.
2. REPAIR STREET PAVING AS PER TRENCH RESTORATION DWG. NO. 6020.
3. REUSE OF REMOVED VALVE, BOX, BURY AND HYDRANT REQUIRES REVIEW AND APPROVAL OF THE WATER DEPARTMENT AND CITY ENGINEER.

INSTALL FIRE HYDRANT ASSEMBLY PER DRAWING NO. 6310

TRACER WIRE PER DWG. NO. 6020

6" C900 (DR18) WATER LATERAL


CUT-IN WATERLINE TIE-IN FOR 6" AND SMALLER MAINS. HOT-TAP TIE-IN FOR 8" AND LARGER MAINS. SEE DWG. NO.S 6310 AND 6335.

AD DETERMINED BY CITY ENGINEER

EXISTING WATER MAIN

EXISTING CURB AND GUTTER

REVISIONS	DATE



CITY OF TULARE PUBLIC IMPROVEMENT STANDARD	
FIRE HYDRANT REPLACEMENT	DRAWING NO.:
Approved By: <i>Michael W. Miller</i> Date: 11/15/16	6320 1 OF 1
City Engineer	